

**Кулачковые переключатели PRICE LIST**

**PRICES: EURO EXW**

**VALIDITY: DECEMBER 2015**

<i>Baan code</i>	<i>Описание</i>	<i>Price List 2015</i>
<b>MOD TP-10 CAM SWITCHES, Ith=12A</b>		
TP-001000010E1N1	Switch-disconnector - ON-OFF - 1P	4,68
TP-001000011E1N1	Switch-disconnector - ON-OFF - 2P	5,72
TP-001000012E1N1	Switch-disconnector - ON-OFF - 3P	6,76
TP-001000013E1N1	Switch-disconnector - ON-OFF - 4P	7,80
TP-001000400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	5,72
TP-001000401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	7,80
TP-001000402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	9,88
TP-001000701E1N1	Volmeter switch - 3 PHASES	7,28
TP-001000705E1N1	Volmeter switch - 3 PHASES AND 3 PHASES TO NEUTRAL	9,36
TP-001000724E1N1	Ammeter switch - 3 PHASES, 2 CURRENT TRANSFORMERS - 1P	7,80
TP-001000731E1N1	Ammeter switch - 3 CIRCUITS, 3 LINES, 3 CURRENT TRANSFORMERS - 1P	11,44
<b>MOD T-12 CAM SWITCHES, Ith=16A</b>		
T-0001200010E1N1	Switch-disconnector - ON-OFF - 1P	9,53
T-0001200011E1N1	Switch-disconnector - ON-OFF - 2P	11,27
T-0001200012E1N1	Switch-disconnector - ON-OFF - 3P	13,25
T-0001200013E1N1	Switch-disconnector - ON-OFF - 4P	14,23
T-0001200020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	18,99
T-0001200021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	20,48
T-0001200022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	20,48
T-0001200101E1N1	Reversing switch - 2P	16,50
T-0001200102E1N1	Reversing switch - 3P	18,24
T-0001200111E1N1	Reversing switch with spring return - 2P	20,48
T-0001200112E1N1	Reversing switch with spring return - 3P	23,54
T-0001200113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	27,99
T-0001200400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	11,83
T-0001200401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	16,17
T-0001200402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	17,78
T-0001200403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	21,73
T-0001200405E1N1	Changeover switch with spring return to center - 1P	22,37
T-0001200406E1N1	Changeover switch with spring return to center - 2P	26,01
T-0001200407E1N1	Changeover switch with spring return to center - 3P	28,93
T-0001200410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	16,65
T-0001200411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	19,25
T-0001200412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	22,89
T-0001200413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	31,21
T-0001200414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	33,29
T-0001200500E1N1	Changeover switch without "OFF" - 1P	11,97
T-0001200501E1N1	Changeover switch without "OFF" - 2P	17,89
T-0001200502E1N1	Changeover switch without "OFF" - 3P	21,94
T-0001200503E1N1	Changeover switch without "OFF" - 4P	24,85
T-0001200510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	18,73
T-0001200511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	26,01
T-0001200512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	29,13
T-0001200513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	33,29
T-0001200700E1N1	Volmeter switch - 2 PHASES AC - 2P DC	18,21
T-0001200701E1N1	Volmeter switch - 3 PHASES	14,58
T-0001200702E1N1	Volmeter switch - 3 PHASES TO NEUTRAL	18,16
T-0001200703E1N1	Volmeter switch - 4 LINES WITH 2 WIRES AC or DC	26,91
T-0001200704E1N1	Volmeter switch - 3 PHASES AND 1 PHASE TO NEUTRAL	20,93
T-0001200705E1N1	Volmeter switch - 3 PHASES TO PHASE AND 3 PHASES TO NEUTRAL	18,28
T-0001200706E1N1	Volmeter switch - 2 SEPARATE 3 PHASE WITH CENTER "OFF"	26,91
T-0001200707E1N1	Volmeter switch for 6 circuits	18,21
T-0001200720E1N1	Ammeter switch - 3 PHASES, 3 CURRENT TRANSFORMERS - 1P	22,35
T-0001200721E1N1	Ammeter switch - 3 PHASES, 2 CURRENT TRANSFORMERS - 1P	18,21
T-0001200722E1N1	Ammeter switch - 3 PHASES, 2 or 3 CURRENT TRANSFORMERS - 1P	31,92
T-0001200723E1N1	Ammeter switch - 3 CIRCUITS, 2 CURRENT TRANSFORMERS - 1P	22,37
T-0001200724E1N1	Ammeter switch - 3 PHASES, 2 CURRENT TRANSFORMERS - 1P	18,21
T-0001200725E1N1	Ammeter switch - 4 CIRCUITS, 4 CURRENT TRANSFORMERS - 1P	26,91
T-0001200726E1N1	Ammeter switch - 2 CIRCUITS, 4 CURRENT TRANSFORMERS - 2P	22,37
T-0001200727E1N1	Ammeter switch - 3 CIRCUITS, 3 CURRENT TRANSFORMERS - 2P	34,96
T-0001200728E1N1	Ammeter switch - 4 CIRCUITS, 4 CURRENT TRANSFORMERS - 2P	36,31
T-0001200729E1N1	Ammeter switch - 1 CIRCUIT - 1P	14,83
T-0001200730E1N1	Ammeter switch - 2 CIRCUITS - 1P	18,21
T-0001200731E1N1	Ammeter switch - 3 CIRCUITS, 3 LINES, 3 CURRENT TRANSFORMERS - 1P	22,54
<b>MOD T-20 CAM SWITCHES, Ith=25A</b>		
T-0002000010E1N1	Switch-disconnector - ON-OFF - 1P	12,29
T-0002000011E1N1	Switch-disconnector - ON-OFF - 2P	13,56
T-0002000012E1N1	Switch-disconnector - ON-OFF - 3P	13,87
T-0002000013E1N1	Switch-disconnector - ON-OFF - 4P	16,75
T-0002000020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	19,72
T-0002000021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	21,37
T-0002000022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	21,37
T-0002000101E1N1	Reversing switch - 2P	17,21
T-0002000102E1N1	Reversing switch - 3P	19,78
T-0002000111E1N1	Reversing switch with spring return - 2P	22,17
T-0002000112E1N1	Reversing switch with spring return - 3P	26,39
T-0002000113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	29,56
T-0002000400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	13,93



T-0002000401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	17,17
T-0002000402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	21,12
T-0002000403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	25,53
T-0002000405E1N1	Changeover switch with spring return to center - 1P	17,23
T-0002000406E1N1	Changeover switch with spring return to center - 2P	21,37
T-0002000407E1N1	Changeover switch with spring return to center - 3P	26,45
T-0002000410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	15,31
T-0002000411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	17,54
T-0002000412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	18,99
T-0002000413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	21,91
T-0002000414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	26,16
T-0002000500E1N1	Changeover switch without "OFF" - 1P	15,43
T-0002000501E1N1	Changeover switch without "OFF" - 2P	19,02
T-0002000502E1N1	Changeover switch without "OFF" - 3P	24,03
T-0002000503E1N1	Changeover switch without "OFF" - 4P	28,60
T-0002000510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	17,54
T-0002000511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	18,99
T-0002000512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	21,91
T-0002000513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	23,51
T-0002000700E1N1	Volmeter switch - 2 PHASES AC - 2P DC	18,99
T-0002000701E1N1	Volmeter switch - 3 PHASES	19,34
T-0002000702E1N1	Volmeter switch - 3 PHASES TO NEUTRAL	20,45
T-0002000703E1N1	Volmeter switch - 4 LINES WITH 2 WIRES AC OR DC	28,36
T-0002000704E1N1	Volmeter switch - 3 PHASES AND 1 PHASE TO NEUTRAL	21,91
T-0002000705E1N1	Volmeter switch - 3 PHASES TO PHASE AND 3 PHASES TO NEUTRAL	24,34
T-0002000706E1N1	Volmeter switch - 2 SEPARATE 3 PHASE WITH CENTER "OFF"	28,36
T-0002000707E1N1	Volmeter switch for 6 circuits	18,99
T-0002000720E1N1	Ammeter switch - 3 PHASES, 3 CURRENT TRANSFORMERS - 1P	26,49
T-0002000721E1N1	Ammeter switch - 3 PHASES, 2 CURRENT TRANSFORMERS - 1P	18,99
T-0002000722E1N1	Ammeter switch - 3 PHASES, 2 or 3 CURRENT TRANSFORMERS - 1P	33,71
T-0002000723E1N1	Ammeter switch - 3 CIRCUITS, 2 CURRENT TRANSFORMERS - 1P	23,51
T-0002000724E1N1	Ammeter switch - 3 PHASES, 2 CURRENT TRANSFORMERS - 1P	18,99
T-0002000725E1N1	Ammeter switch - 4 CIRCUITS, 4 CURRENT TRANSFORMERS - 1P	28,36
T-0002000726E1N1	Ammeter switch - 2 CIRCUITS, 4 CURRENT TRANSFORMERS - 2P	23,51
T-0002000727E1N1	Ammeter switch - 3 CIRCUITS, 3 CURRENT TRANSFORMERS - 2P	36,91
T-0002000728E1N1	Ammeter switch - 4 CIRCUITS, 4 CURRENT TRANSFORMERS - 2P	38,45
T-0002000729E1N1	Ammeter switch - 1 CIRCUIT - 1P	15,31
T-0002000730E1N1	Ammeter switch - 2 CIRCUITS - 1P	18,99
T-0002000731E1N1	Ammeter switch - 3 CIRCUITS, 3 LINES, 3 CURRENT TRANSFORMERS - 1P	26,63

**MOD T-25 CAM SWITCHES, Ith=32A**

T-0002500010E1N1	Switch-disconnector - ON-OFF - 1P	16,34
T-0002500011E1N1	Switch-disconnector - ON-OFF - 2P	18,40
T-0002500012E1N1	Switch-disconnector - ON-OFF - 3P	21,09
T-0002500013E1N1	Switch-disconnector - ON-OFF - 4P	23,11
T-0002500020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	27,55
T-0002500021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	30,15
T-0002500022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	30,15
T-0002500101E1N1	Reversing switch - 2P	24,27
T-0002500102E1N1	Reversing switch - 3P	28,40
T-0002500111E1N1	Reversing switch with spring return - 2P	30,15
T-0002500112E1N1	Reversing switch with spring return - 3P	35,94
T-0002500113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	43,77
T-0002500400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	18,82
T-0002500401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	23,41
T-0002500402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	30,37
T-0002500403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	36,64
T-0002500405E1N1	Changeover switch with spring return to center - 1P	24,00
T-0002500406E1N1	Changeover switch with spring return to center - 2P	30,15
T-0002500407E1N1	Changeover switch with spring return to center - 3P	38,53
T-0002500410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	24,00
T-0002500411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	27,55
T-0002500412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	30,15
T-0002500413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	35,94
T-0002500414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	43,77
T-0002500500E1N1	Changeover switch without "OFF" - 1P	19,53
T-0002500501E1N1	Changeover switch without "OFF" - 2P	26,01
T-0002500502E1N1	Changeover switch without "OFF" - 3P	33,49
T-0002500503E1N1	Changeover switch without "OFF" - 4P	40,34
T-0002500510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	27,55
T-0002500511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	30,15
T-0002500512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	35,94
T-0002500513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	38,53

**MOD T-32 CAM SWITCHES, Ith=40A**

T-0003200010E1N1	Switch-disconnector - ON-OFF - 1P	19,00
T-0003200011E1N1	Switch-disconnector - ON-OFF - 2P	20,57
T-0003200012E1N1	Switch-disconnector - ON-OFF - 3P	23,49
T-0003200013E1N1	Switch-disconnector - ON-OFF - 4P	25,79
T-0003200020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	30,50
T-0003200021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	33,67
T-0003200022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	33,67
T-0003200101E1N1	Reversing switch - 2P	27,12
T-0003200102E1N1	Reversing switch - 3P	32,07
T-0003200111E1N1	Reversing switch with spring return - 2P	33,67
T-0003200112E1N1	Reversing switch with spring return - 3P	42,23
T-0003200113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	49,01
T-0003200400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	20,33

T-0003200401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	26,24
T-0003200402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	34,18
T-0003200403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	41,42
T-0003200405E1N1	Changeover switch with spring return to center - 1P	25,93
T-0003200406E1N1	Changeover switch with spring return to center - 2P	33,67
T-0003200407E1N1	Changeover switch with spring return to center - 3P	43,32
T-0003200410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	25,93
T-0003200411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	30,50
T-0003200412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	33,67
T-0003200413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	40,15
T-0003200414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	49,01
T-0003200500E1N1	Changeover switch without "OFF" - 1P	22,26
T-0003200501E1N1	Changeover switch without "OFF" - 2P	28,50
T-0003200502E1N1	Changeover switch without "OFF" - 3P	34,13
T-0003200503E1N1	Changeover switch without "OFF" - 4P	41,14
T-0003200510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	30,50
T-0003200511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	33,67
T-0003200512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	40,15
T-0003200513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	43,32

**MOD T-40 CAM SWITCHES, Ith=50A**

T-0004000010E1N1	Switch-disconnector - ON-OFF - 1P	19,10
T-0004000011E1N1	Switch-disconnector - ON-OFF - 2P	21,22
T-0004000012E1N1	Switch-disconnector - ON-OFF - 3P	23,93
T-0004000013E1N1	Switch-disconnector - ON-OFF - 4P	26,34
T-0004000020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	31,04
T-0004000021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	34,35
T-0004000022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	34,35
T-0004000101E1N1	Reversing switch - 2P	27,67
T-0004000102E1N1	Reversing switch - 3P	32,72
T-0004000111E1N1	Reversing switch with spring return - 2P	34,35
T-0004000112E1N1	Reversing switch with spring return - 3P	41,01
T-0004000113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	50,19
T-0004000400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	20,62
T-0004000401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	27,18
T-0004000402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	34,94
T-0004000403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	42,28
T-0004000405E1N1	Changeover switch with spring return to center - 1P	26,30
T-0004000406E1N1	Changeover switch with spring return to center - 2P	34,35
T-0004000407E1N1	Changeover switch with spring return to center - 3P	44,34
T-0004000410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	26,30
T-0004000411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	31,04
T-0004000412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	34,35
T-0004000413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	41,01
T-0004000414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	50,19
T-0004000500E1N1	Changeover switch without "OFF" - 1P	22,60
T-0004000501E1N1	Changeover switch without "OFF" - 2P	29,72
T-0004000502E1N1	Changeover switch without "OFF" - 3P	38,55
T-0004000503E1N1	Changeover switch without "OFF" - 4P	46,58
T-0004000510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	31,04
T-0004000511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	34,35
T-0004000512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	41,01
T-0004000513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	44,34

**MOD T-63 CAM SWITCHES, Ith=80A**

T-0006300010E1N1	Switch-disconnector - ON-OFF - 1P	32,94
T-0006300011E1N1	Switch-disconnector - ON-OFF - 2P	35,11
T-0006300012E1N1	Switch-disconnector - ON-OFF - 3P	40,79
T-0006300013E1N1	Switch-disconnector - ON-OFF - 4P	44,97
T-0006300020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	50,46
T-0006300021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	55,46
T-0006300022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	55,46
T-0006300101E1N1	Reversing switch - 2P	46,69
T-0006300102E1N1	Reversing switch - 3P	55,67
T-0006300111E1N1	Reversing switch with spring return - 2P	55,46
T-0006300112E1N1	Reversing switch with spring return - 3P	66,63
T-0006300113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	81,08
T-0006300400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	36,40
T-0006300401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	46,39
T-0006300402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	59,24
T-0006300403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	72,85
T-0006300405E1N1	Changeover switch with spring return to center - 1P	43,29
T-0006300406E1N1	Changeover switch with spring return to center - 2P	55,46
T-0006300407E1N1	Changeover switch with spring return to center - 3P	72,53
T-0006300410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	43,29
T-0006300411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	50,46
T-0006300412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	55,46
T-0006300413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	66,63
T-0006300414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	81,08
T-0006300500E1N1	Changeover switch without "OFF" - 1P	38,04
T-0006300501E1N1	Changeover switch without "OFF" - 2P	48,27
T-0006300502E1N1	Changeover switch without "OFF" - 3P	63,67
T-0006300503E1N1	Changeover switch without "OFF" - 4P	77,91
T-0006300510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	50,46
T-0006300511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	55,46
T-0006300512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	66,63
T-0006300513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	72,53

**MOD T-100 CAM SWITCHES, Ith=125A**

T-0010000010E1N1	Switch-disconnector - ON-OFF - 1P	43,67
T-0010000011E1N1	Switch-disconnector - ON-OFF - 2P	51,99
T-0010000012E1N1	Switch-disconnector - ON-OFF - 3P	59,67
T-0010000013E1N1	Switch-disconnector - ON-OFF - 4P	67,57
T-0010000020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	74,66
T-0010000021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	84,26
T-0010000022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	84,26
T-0010000101E1N1	Reversing switch - 2P	69,61
T-0010000102E1N1	Reversing switch - 3P	84,39
T-0010000111E1N1	Reversing switch with spring return - 2P	84,26
T-0010000112E1N1	Reversing switch with spring return - 3P	101,20
T-0010000113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	126,10
T-0010000400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	51,99
T-0010000401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	69,61
T-0010000402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	93,70
T-0010000403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	115,15
T-0010000405E1N1	Changeover switch with spring return to center - 1P	62,95
T-0010000406E1N1	Changeover switch with spring return to center - 2P	84,26
T-0010000407E1N1	Changeover switch with spring return to center - 3P	109,92
T-0010000410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	62,95
T-0010000411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	74,66
T-0010000412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	84,26
T-0010000413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	101,20
T-0010000414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	126,10
T-0010000500E1N1	Changeover switch without "OFF" - 1P	57,47
T-0010000501E1N1	Changeover switch without "OFF" - 2P	76,94
T-0010000502E1N1	Changeover switch without "OFF" - 3P	100,36
T-0010000503E1N1	Changeover switch without "OFF" - 4P	126,24
T-0010000510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	74,66
T-0010000511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	84,26
T-0010000512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	101,20
T-0010000513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	109,92

**MOD T-200 CAM SWITCHES, Ith=200A**

T-0020000010E1N1	Switch-disconnector - ON-OFF - 1P	105,71
T-0020000011E1N1	Switch-disconnector - ON-OFF - 2P	126,25
T-0020000012E1N1	Switch-disconnector - ON-OFF - 3P	159,05
T-0020000013E1N1	Switch-disconnector - ON-OFF - 4P	185,40
T-0020000020E1N1	ON-OFF switch with contacts leading when making - 3P - 1P preclosed	191,01
T-0020000021E1N1	ON-OFF switch with contacts leading when making - 4P - 1P preclosed	218,92
T-0020000022E1N1	ON-OFF switch with contacts leading when making - 4P - 3P preclosed	218,92
T-0020000101E1N1	Reversing switch - 2P	180,85
T-0020000102E1N1	Reversing switch - 3P	242,42
T-0020000111E1N1	Reversing switch with spring return - 2P	218,92
T-0020000112E1N1	Reversing switch with spring return - 3P	269,12
T-0020000113E1N1	Reversing switch with spring return - 3P (use with reserving contactors)	342,26
T-0020000400E1N1	Changeover switch with center "OFF" 1-0-2 - 1P	126,25
T-0020000401E1N1	Changeover switch with center "OFF" 1-0-2 - 2P	180,85
T-0020000402E1N1	Changeover switch with center "OFF" 1-0-2 - 3P	248,45
T-0020000403E1N1	Changeover switch with center "OFF" 1-0-2 - 4P	326,67
T-0020000405E1N1	Changeover switch with spring return to center - 1P	152,83
T-0020000406E1N1	Changeover switch with spring return to center - 2P	218,92
T-0020000407E1N1	Changeover switch with spring return to center - 3P	302,75
T-0020000410E1N1	Multi-step switch with "OFF" position - 1P, 2 POSITIONS	152,83
T-0020000411E1N1	Multi-step switch with "OFF" - 1P, 3 POSITIONS	191,01
T-0020000412E1N1	Multi-step switch with "OFF" - 1P, 4 POSITIONS	218,92
T-0020000413E1N1	Multi-step switch with "OFF" - 1P, 5 POSITIONS	269,12
T-0020000414E1N1	Multi-step switch with "OFF" - 1P, 6 POSITIONS	342,26
T-0020000500E1N1	Changeover switch without "OFF" - 1P	139,54
T-0020000501E1N1	Changeover switch without "OFF" - 2P	199,89
T-0020000502E1N1	Changeover switch without "OFF" - 3P	276,43
T-0020000503E1N1	Changeover switch without "OFF" - 4P	354,04
T-0020000510E1N1	Multi-step switch without "OFF" position - 1P, 3 POSITIONS	191,01
T-0020000511E1N1	Multi-step switch without "OFF" position - 1P, 4 POSITIONS	218,92
T-0020000512E1N1	Multi-step switch without "OFF" position - 1P, 5 POSITIONS	269,12
T-0020000513E1N1	Multi-step switch without "OFF" position - 1P, 6 POSITIONS	302,75







